

Marblestone Italian Lime Interior Finishes - Plasterboard RenderSpec

General

Building Code Compliance

If the project has a building consent then the following clauses apply.

B2 - Durability

This specification complies with the requirements as set out in B2 - Durability which must always be considered when demonstrating compliance with each of the clauses of the Building Code. It ensures that a building throughout its life will continue to satisfy the performance of the Building Code. It confirms the use of materials that will remain functional throughout the specified intended life of the building, but not less than 50, 15 or 5 years

This system meets the expected durability of the NZBC of at least 5 years

F2 - Hazardous building materials

This specification complies with the requirements as set out in F2 - Hazardous building materials which safeguards people from illness and injury from quantities of gas, liquid, radiation and solid particles caused by exposure to building materials

On Going Maintenance Instructions

Provide ongoing maintenance instructions required to meet the performance requirements of the NZBC.

Building Consent Authority Requirements

All the appropriate inspections are to be carried out by a BCA representative and that it complies with the NZBC requirements.

Documents

Abbreviations

The following abbreviations are used throughout this work section:

- BCA - Building Consent Authority
- LBP - Licensed Building Practitioner
- PPCS - Proprietary Plaster Cladding System
- MPNZA - Master Painters of New Zealand Association
- MSDS - Material Safety Data Sheet
- NZBC - New Zealand Building Code

Manufacturers Documents

Copies of the above relevant company documents referred to in this specification are available at;

Resene Construction Systems
Web: reseneconstruction.co.nz
Telephone: [0800 50 70 40](tel:0800507040)

No Substitutions

Substitutions are not permitted to any specified Resene Construction Systems system. Materials and execution to Resene Construction Systems specification except where varied by this specification and supported by architectural detailing.

Documentation

Finish Sample

Submit one 300 mm x 300 mm sample of the selected texture finish and colour for approval on request by the main contractor or specifier. Obtain signature of acceptance on sample and return to the Registered Plasterer.

Maintenance Instructions

Provide Resene Construction Systems Maintenance Guide on or before practical completion of the contract for issuing to the building owner. Resene Construction Systems Maintenance Guide to be provided on request.

Health and Safety

Refer to the requirements of the Health and Safety in Employment Act 2015 and Worksafe NZ: Guidelines for the provision of facilities and general safety in the construction industry. If the elimination or isolation of potential hazards and risks is not possible then minimise hazards and risks in this work on site by using the proper equipment and techniques as required in the MPNZA Painters hazard handbook. Supply protective clothing and equipment. Inform employees and others on site of the hazards and put into place procedures for dealing with emergencies. Obtain from Resene Construction Systems the Material Safety Data Sheets for each product. Keep sheets on site and comply with the required safety procedures. Confirmation at the start of the project as to whether a Site Specific Safety Plan is to be produced by the Registered Plasterer prior to works starting.

Warranty

Warrant this system under normal environmental and use conditions against failure. Resene Construction Systems system warranty.

Materials: by Resene Construction Systems - 15 Years Materials only

Execution: by Registered Plasterer - 5 Years Workmanship only

Components Used

Resene Quick Dry

- Resene Quick Dry waterborne primer undercoat provides long-term flexibility over unstable substrates coupled with exceptional durability even when left uncoated for prolonged periods.
- Installed over the plastered joins prior to a full sealer coat/slurry coat

Acrylbond Resin

- Multi-purpose Resin supplied in 5kg and 20kg containers

MultiStop Bedding Compound

- Polymer-modified, cement based dry plaster mix. Supplied in 15kg bags.

Marblestone AquaWax

- Supplied in 1kg pails
- Used to repel water from the Milano surface

Installation/Application

Check and Prepare Plasterboard Linings

Preparation based on new substrate installations.

2.8.1.Preliminary Checks

Plasterboard must be taped and stopped to a level 4 finish according to Plasterboard manufacturer's specifications.

2.8.2.Clean Surface

If the substrate has been left for a period of time, dust and dirt may build up on the surface. This contamination must be removed prior to application of paints and Render.

2.8.3.Masking

Before application of paints and Render apply masking to all areas likely to be marked by the Render. Use drop cloths and ground covers to keep the working areas clean.

Resene Quick Dry (over plastered joins)

Application

Apply by brush, speed brush, synthetic fibre roller or spray. Spray application is generally not preferred for the first coat.

Apply one to two coats of Resene Quick Dry allowing two to four hours between coats. Lightly sand between coats. For porous surfaces, it may be desirable to thin the first coat with up to 10% clean water.

Resin/MultiStop Slurry Coat

Surface Preparation

Ensure surface is clean, sound, dry and free from dust, dirt, grease, mould and lichen.

Application

Mix a solution of Acrylbond and Rockcote MultiStop together and apply using a roller or brush. A high solids roller can also be used to ensure the solution is evenly distributed across the wall surface.

For pourous substrates (eg. brick, concrete) mix a 50:50 4L mix of Acrylbond/water and a 1 kg of MultiStop/AAC Adhesive/Hydroplast to the mix.

For other surfaces (including painted) ensure a 4 Litre of Acrylbond is mixed directly with 1 kg of MultiStop/AAC Adhesive/Hydroplast.

If you are unsure of the surface you are applying the slurry to, apply to a small section of wall and test for adhesion.

Milano Marblestone BaseCoat

The product is ready to-use and it is thixotropic: mix it gently until it is workable. Should there be a liquid surface layer present, this will not affect the quality of MARBLESTONE. Apply MARBLESTONE using a metal trowel, waiting 24 hours before applying the second coat.

Milano Marblestone (2 Coats)

Apply the second coat with a steel trowel once the material acquires firmness, smooth off with a stainless steel trowel. Allow at least 24 hours to elapse before apply MARBLESTONE PLAK.

Milano Plaq

Spread on using a stainless steel trowel and, once it starts to harden, press smooth repeatedly until the surface is perfectly compact and shiny. For a deeper and more uniform finish, spread on two layers of MARBLESTONE PLAK.

Milano AquaWax

Important:

This specification must be read in conjunction with the Resene Construction Systems technical drawings.

No alteration to the Resene Construction Systems RenderSpec® is permitted.

All Technical Data Sheets are available at <https://reseneconstruction.co.nz/technical-library/technical-data-sheets/>

All Safety Data Sheets are available at <https://reseneconstruction.co.nz/technical-library/safety-data-sheets/>