

# **XTHERM GOLD Insulated Facade System - 50mm XTherm Gold over Timber Frame - Mineral RenderSpec**

## **General**

### **Description of Works/Specification Notes**

This specification deals with the Resene Construction Systems Insulated Facade System applied over a 50mm XTherm Gold sheet substrate. The system incorporates the installation of a 20mm drainage cavity and mineral texture finish.

Thickness – 56mm (min/average excl cavity size)

Weight – 7 kg/m<sup>2</sup>

Windzone – All wind zones of 3604 and specific design wind pressures up to 2.5kPa design differential ULS

Durability – 15 year warranty / expected durability from BRANZ 30 years

Testing – BRANZ appraisal certificate # 633(2018)

## **Building Code Compliance**

If the project has a building consent then the following clauses apply.

### **B1 - Structure**

This specification complies with the requirements as set out in B1 - Structure which requires buildings, building elements and sitework to withstand the combination of loads and physical conditions they are likely to experience during construction, alteration and throughout their lives. Loads and physical conditions include self-weight, temperature, water, earthquakes, snow, wind, fire.

### **B2 - Durability**

This specification complies with the requirements as set out in B2 - Durability which must always be considered when demonstrating compliance with each of the clauses of the Building Code. It ensures that a building throughout its life will continue to satisfy the performance of the Building Code. It confirms the use of materials that will remain functional throughout the specified intended life of the building, but not less than 50, 15 or 5 years

This cladding system meets the expected durability of the NZBC of at least 15 years

### **E2 - External Moisture**

This specification complies with the requirements as set out in E2 - External Moisture which demonstrates External roof, wall claddings and external openings will prevent external moisture from causing undue dampness or damage.

### **F2 - Hazardous building materials**

This specification complies with the requirements as set out in F2 - Hazardous building materials which safeguards people from illness and injury from quantities of gas, liquid, radiation and solid particles caused by exposure to building materials

### **On Going Maintenance Instructions**

Provide ongoing maintenance instructions required to meet the performance requirements of the NZBC.

### **Building Consent Authority Requirements**

All the appropriate inspections are to be carried out by a BCA representative and that it complies with the NZBC requirements.

## **Documents**

### **Abbreviations**

The following abbreviations are used throughout this work section:

- BCA - Building Consent Authority
- LBP - Licensed Building Practitioner
- PPCS - Proprietary Plaster Cladding System
- MPNZ - Master Painters of New Zealand Association

- MSDS - Material Safety Data Sheet
- NZBC - New Zealand Building Code

## Manufacturers Documents

Copies of the above relevant company documents referred to in this specification are available at;

Resene Construction Systems  
Web: [reseneconstruction.co.nz](http://reseneconstruction.co.nz)  
Telephone: [0800 50 70 40](tel:0800507040)

## No Substitutions

Substitutions are not permitted to any specified Resene Construction Systems system. Materials and execution to Resene Construction Systems specification except where varied by this specification and supported by architectural detailing.

## Qualifications

Use only LBP registered plasterers licensed to apply the Resene Construction Systems exterior render systems.

## Documentation

### Finish Sample

Submit one 300 mm x 300 mm sample of the selected texture finish and colour for approval on request by the main contractor or specifier. Obtain signature of acceptance on sample and return to the Registered Plasterer.

### Maintenance Instructions

Provide Resene Construction Systems Maintenance Guide on or before practical completion of the contract for issuing to the building owner. Resene Construction Systems Maintenance Guide to be provided on request.

### Producer Statement

If the project has a building consent then a producer statement shall be supplied by the plasterer in the form as required by the BCA.

### Health and Safety

Refer to the requirements of the Health and Safety in Employment Act 2015 and Worksafe NZ: Guidelines for the provision of facilities and general safety in the construction industry. If the elimination or isolation of potential hazards and risks is not possible then minimise hazards and risks in this work on site by using the proper equipment and techniques as required in the MPNZA Painters hazard handbook. Supply protective clothing and equipment. Inform employees and others on site of the hazards and put into place procedures for dealing with emergencies. Obtain from Resene Construction Systems the Material Safety Data Sheets for each product. Keep sheets on site and comply with the required safety procedures. Confirmation at the start of the project as to whether a Site Specific Safety Plan is to be produced by the Registered Plasterer prior to works starting.

### Warranty

Warrant this system under normal environmental and use conditions against failure. Resene Construction Systems system warranty.  
Materials: by Resene Construction Systems - 15 Years Materials only  
Execution: by Registered Plasterer - 5 Years Workmanship only

### OnSite Assistance

Allow to inspect the whole of the work at each stage. Determine a programme for onsite assistance including notification when each part and stage of the work is ready for inspection prior to the work commencing. Permit representatives of Resene Construction Systems to inspect the work in progress and to take samples of their products from site if requested.

## Components Used

### Resene Construction Systems Battens - Graphex 20mm

- 40mm x 20mm H-Grade Graphex Peel and Stick Batten
- Supplied in Boxes
- 228 units in a box

- AS 1366 Part 3 Class H (with fire retardant).

## **XTherm Gold 50mm**

- 2400 x 1200
- 50mm Thick
- Allow for 7% Wastage when Installing
- AS 1366 Part 3 (with fire retardant).

## **Soudal Gorilla Pro Expanding Foam Click & Fix**

- It uses CFC-free propellants which are completely harmless to the ozone layer.
- Excellent adhesion on most materials, including Polystyrene (except PE/PP & Teflon)
- High thermal and acoustical isolation
- Very good filling capacity
- Excellent bonding and installing capacity
- 50% less propellant
- Excellent mounting capacity
- Remains waterproof providing the integrity of the skin of the cured foam is maintained
- Draft Proof and Pest Resistant (Note: Rodents and persistent boring pests may over time make their way through the product)

## **Nails (Preloaded) 100mm**

- Flat-head, hot-dipped galvanised and 40 mm diameter nylon washers.
- 100mm x 4.0mm

## **Resene Construction Systems Cavity Closer (20-30mm)**

- Supplied in 2400mm Lengths
- Suitable for 20-30mm Cavities

## **Resene Construction Systems Channel - 50mm**

- Supplied in 2400mm Lengths
- Suitable for 50mm Substrates

## **Resene Construction Systems EdgeSeal Window Flashing**

- Used for sill and jamb installations
- Supplied in 2400mm lengths

## **Resene Construction Systems EdgeSeal Head Flashing**

- Supplied in 2.4m Lengths
- Generally requires the Drip Edge Flashing

## **Resene Construction Systems Drip Edge - Small**

- Supplied in 2400mm Lengths
- Used with both the EdgeSeal Head Flashing and also the Universal Starter Strip

## **Resene Construction Systems Pre-meshed Corners**

- Supplied in 2400mm Lengths

## **Soudal Holdfast Nailpower Construction Adhesive**

Holdfast Nailpower Construction Adhesive is a high performance, paste like construction adhesive formulated to bond a variety of common construction materials.

Supplied in 375mls cartridges

## **Acrylbond Resin**

- Multi-purpose Resin supplied in 5kg and 20kg containers

## MultiStop Bedding Compound

- Polymer-modified, cement based dry plaster mix. Supplied in 15kg bags.

## Coarse Mesh Render

- Supplied in 20kg Bags

## Mesh - Blue (1200mm wide)

- Alkali Resistant 6mm x 5mm Weave mesh supplied in 50m rolls

## Ezytex Float

- Polymer-modified cement-based dry plaster mix. Supplied in 20 kg bags

## Resene Limelock

- Water based acrylic polymer dispersion. Supplied in 10 litre pails.

## Resene X200

- Acrylic reinforced waterproof membrane. Supplied in 4 and 10 litre pails. Tinted to the selected colour

## Soudal Gorilla MS Sealant White

Gorilla MS is a high performance MS sealant, which is UV-resistant, waterproof, paintable\*, solvent-free and with superior flexibility.

Ideal for the sealing of expansion and connection joints with a wide range of movement. Suitable for a wide range of substrates including blockwork, brickwork, granite, marble, timber, coated and uncoated aluminum.

Supplied in 420gm cartridges

### Features and Benefits:

- Non slump
- The whitest of whites
- 900% elongation of break
- High performance MS
- BRANZ Appraised
- Works on damp surfaces
- Paintable 1 hour after application
- UV resistant
- AsureQuality tested
- Easily repairable
- Interior & exterior
- Solvent-free

## Installation/Application

### Timber Frame

#### Check Fixings

It is the builder's or framing installer's responsibility to ensure it is set out true in the correct alignment, as required by the Designer. Before installing insulation boards, check framing is true and in the correct alignment with studs at a 600 mm maximum centres, dwangs/nogs are at no greater than 1200mm (800mm is a distance which is recommended), and blocking is provided for support of the substrate, e.g., around all openings, at soffits, at joints, and at internal corners.

All framing must comply with the requirements of NZS 3604 Light Timber Frame buildings not requiring specific design, or be to a specific structural design.

Ensure that any framing has a moisture content of no more than 18% mc prior to installing substrate. Refer to E2/AS1 section 11

#### Alignment of Walls

To be plumb, level and in true alignment.

A check should be made prior to render installation, using a straight edge to ensure the wall is flat. Any irregularities should be taken out by straightening the studs.

Builder to re-align framing when it is not in the correct alignment, and insert additional blocking if required.

### **Builder Supplied Flashings**

Make sure all builder metal flashings, saddles flashings and back flashings are in place.

## **Battens - Graphex 20mm**

### **General**

*Drained and ventilated cavities are seen as one way of dealing with moisture that may enter through the exterior envelope. Resene Construction Systems recommends the use of cavities.*

When a drainage cavity is used, it should consist of an air space outboard of a building underlay fixed to the framing, with approved flashings to drain water to the outside face of the cladding.

### **Limitations**

Vapour from freshly LOSP-treated timber may melt styrene based battens.

### **Fixing Battens**

Adhesive fixing to the building underlay. This is probably the quickest method of fixing battens. The adhesive acts as a temporary fixing, and it will be permanently fixed upon nailing the substrate in place. Under no circumstances should any solvent-based adhesives be used, as these will melt the battens.

Remember the battens only need to be temporarily held in place, for when you fix the substrate at the appropriate centres this will secure all the battens in place.

**Fix vertical battens on stud lines. Vertical battening must be the full height of the cavity, but battens may be joined (buted) to achieve this.**

Take account of where cladding fixings will be needed for the exact location of the battens. For example, at corners or cladding junctions, provide additional or wider battens as required for fixing the cladding, back-flashings or facings.

Where an intermediate or horizontal fixing is required, for example to fix the top or bottom edge of sheet cladding, install a cavity spacer (short length of batten) on a minimum 5° slope. Leave a minimum 50 mm gap between the spacer and the vertical battens (the gap is to provide drainage and ventilation)

### **Closing off the top of the cavity**

Ventilation is not required at the top of a cavity (note that masonry veneer uses a different cavity system that does require top venting)

Close off the top of the cavity to prevent damp air from the cavity getting into interior spaces, roof framing or eaves. This is particularly important where the cavity finishes beneath a soffit or other area that might be open to a roof space.

One way of closing off the top of the cavity is to use a continuous length of horizontal batten as shown in Figure 9. The horizontal batten also supports fixings at the top edge of sheet claddings where required.

### **Cavity walls over two storeys**

Refer to E2/AS1 Paragraph 9.1.9.4

Cavities may be continuous up to two storeys or 7m maximum but not more, due to limits on drainage and drying. If the wall is greater than two storeys or 7m, divide the cavity using a horizontal flashing that bridges the cavity. Provide ventilation to the cavity above the junction, as described for the base of the wall.

It is the builder's responsibility for the supply and installation of the horizontal flashing according to E2/AS1.

### **Existing Substrates – over timber framing**

Generally deals with existing weatherboard or rigid backing boards (fibre cement sheet)

Battens must be screw fixed to ensure positive fixing through to the structural framing.

*Screw fixing of battens is recommended as existing internal linings may be damaged if nails are hammered into the structural framing.*

## **Xtherm Gold Sheets 50mm**

There must be no horizontal surfaces which will be subject to water ponding; a minimum slope of 5 degrees is required (for metal caps only, 10 degrees for liquid membranes).

### **Ground Clearances**

It is important that ground clearances are maintained after completion and occupation of the building, with the exterior ground sloped to carry water away from the exterior walls.

### **Garage floors**

Need to be low enough to drive onto and high enough to provide a minimum 50 mm step-down to exterior paving, while maintaining cladding clearances either side of the garage door. To achieve this it may be necessary to construct the garage floor lower than the floor level of the building.

In these situations, providing a 'nib' at garage doorways allows the cladding to continue in a straight line while maintaining minimum clearances at the bottom of wall cavities for ventilation.

E2/AS1 : reference section 9.1.3 and Figure 65 and Table 18

It is the landscaper or other external contractor's responsibility for ground-level compliance in relation to cladding clearance and that ground clearances are maintained after completion and occupation of the building.

**Decking Clearances / Level thresholds**

35mm minimum clearance at the highest point of the deck to the cladding is required.

E2/AS1 : reference section 7.0

**Control/Expansion Joint Set outs**

- Where columns intersect beam work control joints should be formed so that they are running vertically and horizontally of the intersection
- Large doors & windows ie Ranch Sliders, & Bi-Fold type where the window area is greater than 8.0m2
- Junctions between dissimilar materials, ie Masonry to Resene Construction Systems XPS System
- Where there are small widths of plaster (ie. less than a trowel width)
- Where the wall length is greater than 8 metres in length a vertical control joint will need to be installed
- Where a two-storey dwelling wall height exceeds 6 metres a horizontal control joint is required
- Control Joints are required at all inter-floor levels on multi-level construction (eg. 3 or more floors)

**2.6.6.Substrate Installation**

XTHERM Gold insulation boards can be installed either horizontally or vertically. If they are installed horizontally then they must be installed in a stretcher bond pattern, butt-jointed tight against each other.

All sheet edges connecting against each other must have Gorilla ProFoam applied along all edges prior to installing the next sheet. All gaps left after XTHERM Gold insulation boards have been installed must be filled using Gorilla ProFoam

**Substrate Preparation**

Check should be made using a straight edge to ensure the wall is flat, plumb and true. Any irregularities should be taken out by straightening using a rasp.

The substrate must be rasped to provide keying for the Render application.

The Render coating is not designed to straighten deviations that exceed the specified Render System thickness.

Once the substrate is deemed ready for plaster, then the main contractor can continue to fix the internal linings. This is so that the main contractor can minimise the chance of any damage to the external plaster cladding that may be caused by the fixing process of the internal linings.

**Nails (Preloaded) 100mm**

Fix insulation boards with fasteners and washers as given in the Table 1 – Fastener Sizes

Fix fasteners into studs at the fixing centres shown in Table 2 – Fastening centres.

Fixings must be flush with the recess in the washer, so that the washer is hard against the insulation board, and pulls the sheet hard back against the framing / batten.

**Table 1 – Fastener Sizes**

8g x 100 mm \*\* 8g x 100 mm \*\*

Substrate Thickness (mm)	Timber Frame Nail size	Timber Frame Screw size	Timber Frame Screw size (countersinking)	Steel Frame Screw size
40mm +20mm Batten	90 x 3.55 mm *	8g x 80 mm **	8g x 70 mm **	8g x 80 mm **
50mm +20mm Batten	100x 4.0 mm *	8g x 100 mm **	8g x 80 mm **	8g x 100 mm **
60mm +20mm Batten	110x 4.0 mm *	8g x 100 mm **	8g x 80 mm **	8g x 100 mm **
75mm +20mm Batten		10g x 120 mm **	8g x 100 mm **	
80mm +20mm Batten		10g x 120 mm **	8g x 100 mm **	
100mm +20mm Batten		12g x 150 mm **	10g x 120 mm **	

\* Nail type = Galvanised flat head

\*\* Screw type = Class 4, countersunk

**Table 2 – Fastening centres**

NZS 3604 Building	Maximum vertical fixing centres	Maximum horizontal fixing centres (mm) along	Maximum horizontal fixing centres
-------------------	---------------------------------	--	-----------------------------------

Wind Zones	(mm) along studs	top and bottom plates	(mm) along dwangs
Low	300	300	300
Medium	300	300	300
High	300	300	300
Very High	200	200	200
Extra High	150	200	150

## 50mm Substrate and 20mm Cavity Flashing Solution

### General Notes

Comply with the Trade Specific penetration flashing guidelines. Carry out to the required standard of execution to ensure water does not penetrate.

Refer to Resene Construction Systems technical drawings for the specified system being installed.

### Priming Flashings

All Resene Construction Systems Flashings must be primed. It is a requirement of Resene Construction Systems to use a solution of 50% Acrylbond, 50% Water and Rockcote MultiStop Bedding compound or AAC Panel Compound. This is then brushed onto the flashings and left 24 hours so that it can adhere and cure.

### Fixing flashings

Use 40mm clouts to temporarily fix flashings in place.

### Starter Strip/Channel Installation

Must be installed directly after sheet installation at ground level to prevent contamination of the bottom edge.

### Vertical control joint installation

Where a vertical control joint intersects with starter strips, the starter strip must be cut to allow for substrate movement.

10mm space between adjacent substrates must be allowed for the positioning of the horizontal control joint.

Must be one continuous length. If the cladding section exceeds flashing length, the joint must be under-flashed with Butyl based flashing tape to the underside of the flashing prior to installation.

### Horizontal control joint installation

30mm space between adjacent substrates must be allowed for the positioning of the horizontal control joint.

Must be one continuous length. If the cladding section exceeds flashing length, or at an external or internal corner the joint must be under-flashed with EIFS butyl tape to the underside of the flashing prior to installation.

### Corner Beads

Fix to external corners or other exposed edges of the substrate ensuring a plumb, straight edge is formed.

### Dissimilar cladding junctions

Refer to Resene Construction Systems and adjacent cladding manufacturers technical drawings.

#### Horizontal

Must have apron/z-flashing installed unless otherwise detailed.

#### Vertical junction

Must have back flashing installed prior to cladding installation.

10 – 15mm space must be provided from any adjacent cladding/substrate.

Oversize PEF Backing Rod must be inserted into the space 5mm-7mm below the outside line of the cladding.

Sealant must be applied to this junction.

### EdgeSeal™ Flashing Suite Installation

#### Preparation – aluminium joinery

Clean the surface/substrate to which the Resene Construction Systems EdgeSeal™ Flashing Suite is being applied with Resene Construction Systems IPA wipes. Lightly rub the surface to which you are applying the Resene Construction Systems EdgeSeal™ Flashing Suite.

This process degreases and removes any pre and post-construction site residue.

DO NOT USE OTHER NON APPROVED CLEANER as the powder coat warranty may be voided.

Ensure the joinery has been set out of the framing at least 20mm or outside the line of the battens.

The EdgeSeal™ Flashing Suite acquires maximum hold after 72 hours. Cladding installation can continue during this curing period. Once cured the flashing cannot be removed without difficulty and risk of damage to the surface to which it adheres.

The EdgeSeal™ Flashing Suite can be made up of 2 lengths, please ensure that the flashing is tightly butted with the adjoining flashing.

### **Joinery Screws**

If the Aluminium joinery has protruding screws along any edge, then you must trim the EdgeSeal™ Window Flashing adhesive and uPVC edge accurately around these and seal with MS sealant prior to priming.

### **Drainage holes**

If the Aluminium joinery has drainage holes located along the underside of the aluminium 'sill' edge you must leave these areas clear of plaster and sealant. When you are installing the EdgeSeal Flashing make sure you remove out a section of the EdgeSeal Flashing so that the drainage holes on the joinery are left clear. The upstand on the EdgeSeal Flashing must remain upright and continuous behind the holes. This will prevent wind-driven rain from entering the back of the cavity, and maintain drainage to the outside face of the cladding system.

### **EdgeSeal™ Sill Installation**

1. Measure the length of EdgeSeal™ Window Flashing 'oversize' by 10mm (5mm on each side of the opening).
2. This measurement is to the outside edge of the 'flexible elbow' of the jamb flashing.
3. To ensure accuracy 12mm past the outside edge of the opening.
4. Remove a corner of the backing tape from the adhesive edge of the prepared flashing.
5. Applying horizontally across the edge of the aluminium joinery so that the edge of the adhesive is flush, not proud of the front face of the aluminium joinery.
6. Slowly pull off the tape while holding the flashing in position
7. Apply pressure to the front of the flashing to make sure an adequate bond has been achieved between flashing and joinery
8. Tack the flashing in place to maintain its shape

### **EdgeSeal™ Jamb Installation**

1. Measure the length of the jamb from the top corner of the joinery unit to the exposed surface of the installed EdgeSeal™ sill flashing.
2. Cut the Rockcote EdgeSeal™ Window Flashing approximately 1mm proud of total length – cutting 1mm extra length will allow for a tight 'compressed' joint where the EdgeSeal™ Window Flashing junctions to the sill.
3. Remove 100mm of the backing tape from the adhesive edge of the prepared flashing.
4. Install the flashing by slipping and butting firmly under the EdgeSeal™ Window Head Flashing (or aluminium flashing depending on what is being used) first, then align the front edge of the flashing flush with the joinery unit..
5. Slowly pull off the tape while holding the flashing in position.
6. Apply pressure to the front of the flashing to make sure an adequate bond has been achieved between the flashing and joinery unit.
7. Tack the flashing in place to maintain its shape

### **EdgeSeal™ Head Installation**

1. Measure the length of the Window Head and allow an extra 5mm on either side of the joinery unit ( sill flashing should be measured and cut to the same dimension)
2. Cut the EdgeSeal™ Window Head Flashing to length.
3. Remove 100mm of the backing tape from the adhesive edge of the prepared flashing.
4. Place the EdgeSeal™ Window Head Flashing on top of the Window Head and slowly pull off the tape while holding the flashing in position
5. Apply firm pressure to the front of the flashing to make sure an adequate bond has been achieved between flashing and joinery
6. Using the same measurement as above, cut a length of Head Flashing tape that is compatible with the building wrap (eg. 3M All Weather Flashing Tape)
7. Adhere the Head Flashing Tape to the top part of the EdgeSeal™ Window Head Flashing and run this up onto the building wrap
8. At either end create a small stop end by turning up the tape against the cavity batten, you need to prevent moisture from tracking off the ends of the Flashing Tape.
9. Install the cladding substrate and decide whether you are plastering or painting the heads.
10. If you are painting the heads install the Universal Drip Edge Flashing between the cladding substrate and the EdgeSeal™ Window Head Flashing

## **Check and Prepare XPS**

Preparation based on new substrate installations.

### **Preliminary Checks**

Check should be made using a straight edge to ensure the wall is flat, plumb and true. Any irregularities should be taken out by straightening using a rasp.

XPS substrate must be rasped to provide keying for Render application.

The Render coating is not designed to straighten deviations which exceed the specified Rockcote Render System thickness.

Once the substrate is deemed ready for plaster then the main contractor can continue to fix the internal linings, this is so that the main contractor can minimise the chance of any damage to the external plaster cladding that may be caused from the fixing process of the internal linings.

### **Clean Surface**



If the substrate has been left exposed to UV / sunlight for more than two weeks, dust and dirt may build up on the surface, the surface may also discolour (yellow) you must remove all surface dust, oxidation, and other contaminants to reveal fresh polystyrene. Use a rasp or a stiff broom to prepare the substrate.

### **Masking**

Before application of Render, apply masking to all joinery, pipes, roofs and all areas likely to be marked by the Render. Use drop cloths and ground covers to keep the working areas clean.

### **Colour selection**

For further information on Light Reflectance Values (LRV) refer to information located at <https://reseneconstruction.co.nz/light-reflectance-values/>

### **Penetrations**

PVC sheathed electrical cables must be prevented from direct contact with the sheets. When cables must penetrate the sheets for exterior electrical connections, the cable must be directly supported by passing through an electrical conduit.

## **Resin/MultiStop Slurry Coat**

### **Surface Preparation**

Ensure surface is clean, sound, dry and free from dust, dirt, grease, mould and lichen.

### **Application**

Mix a solution of Acrylbond and Rockcote MultiStop together and apply using a roller or brush. A high solids roller can also be used to ensure the solution is evenly distributed across the wall surface.

For pourous substrates (eg. brick, concrete) mix a 50:50 4L mix of Acrylbond/water and a 1 kg of MultiStop/AAC Adhesive/Hydroplast to the mix.

For other surfaces (including painted) ensure a 4 Litre of Acrylbond is mixed directly with 1 kg of MultiStop/AAC Adhesive/Hydroplast.

If you are unsure of the surface you are applying the slurry to, apply to a small section of wall and test for adhesion.

## **Plaster Systems Coarse Mesh Render - Base Coat**

### **Surface Preparation**

Ensure surface is clean, sound, dry and free from dust, dirt, grease, mould and lichen.

### **Application**

Plaster can be applied with a steel trowel, pump or broad-knife at approximately 3-5mm thick (3m<sup>2</sup> per bag). Apply plaster only when the temperature is between 5°C and 30°C and will be in that range for the 24 hours period following application.

### **Curing:**

Render should be protected from hot drying winds and direct sunlight for the first 16 hours. Protect newly applied plaster from rain and water run off for the first 24 hours.

## **Resene Construction Systems Mesh (Standard Weave)**

### **General**

Measured and cut slightly longer than the height/length of the area to be covered.

### **Application of Fibreglass Mesh**

Apply the pre-measured mesh from the top of the wall.

Press the fibreglass mesh into the render mix with a steel trowel starting at the centre and working outwards towards the sides, so that it is completely embedded with the render mix forced right through the mesh holes.

Ensure there are no wrinkles or trapped bubbles in the mesh and that it is fully embedded just below the surface of the render.

Do not embed the leading edge of mesh as this locates your next mesh layer.

Mesh must not be exposed but retained as close to the surface as possible.

Overlap mesh 100 mm with the adjacent drop of mesh, and trowel to embed together.

Ensure the fibreglass mesh covers all exposed areas of the substrate, including any recesses around the exterior joinery and internal corners.

Fibreglass Mesh must be bought to the outside edge of all Flashings.

Apply 450 x 150 mm strips of fibreglass mesh 'butterflies' diagonally at every corner of openings for window and door joinery, meter boxes etc.

After the render mix has cured, trim off excess length accurately against the flashing edge.

## Plaster Systems Coarse Mesh Render - Level Coat

### Surface Preparation

Ensure surface is clean, sound, dry and free from dust, dirt, grease, mould and lichen.

### Application

Plaster can be applied with a steel trowel, pump or broad-knife at approximately 2-3mm thick (6m<sup>2</sup> per bag). Apply plaster only when the temperature is between 5°C and 30°C and will be in that range for the 24 hours period following application.

### Curing:

Render should be protected from hot drying winds and direct sunlight for the first 16 hours. Protect newly applied plaster from rain and water run off for the first 24 hours.

## Plaster Systems Ezytex Float Texture Finish

### Application:

Plaster is applied not less than 1mm (8m<sup>2</sup> per bag) with a steel trowel to a flat finish then float using a circular action to an even texture over the following five minutes with a plastic float. Apply plaster only when the temperature is between 5°C and 30°C and will be in that range for the 24 hours period following application.

### Curing:

Plaster should be protected from hot drying winds and direct sunlight for the first 16 hours. Protect newly applied plaster from rain and water run off for the first 24 hours. It is able to be sealed while the finish is still green.

## Resene Limelock Sealer

### Application

Apply to trowelled plasters immediately after final trowelling (Dependent on surface porosity, typically 5-8m<sup>2</sup> per litre). Apply one coat of Resene Limelock over the fresh substrate by commercial grade knapsack sprayer, spray, long pile roller or brush and allow to dry. Evenly coat all fresh surfaces to ensure uniform curing and that free lime cannot be transferred through weak points.

## Resene X200 Paint Finish (2 Coats)

### Application

Use a 12-20mm synthetic fibre roller or texturing roller depending on surface. Apply two coats, First coat 2 sq. metres per litre, Second coat: 3.5 sq. metres per litre

### Maintenance

Plan what maintenance you propose to undertake.

Take into consideration the type of work that is required, & the time of year you want to get it done. Most external maintenance is completed in the summer as this is generally the best weather for drying and for general outside work such as gardening. If you are planning on fixing brackets, security lights or any other fixture to the exterior make sure you have the skills & equipment to undertake the task.

If you are unsure call a specialist.

If it relates to a penetration through the exterior cladding call us direct on 0800 50 70 40 - a simple phone call could save you time & money later. Maintenance sounds difficult & costly - in fact, it can be quite the opposite.

It can become difficult & costly if it is never undertaken, by which time other issues may have arisen that could have been acted upon sooner through regular general maintenance.

There are virtually no "maintenance free" exterior claddings on the market, in fact, almost nothing is maintenance-free - many people tend to throw things away these days when they breakdown as it is cheaper than getting it fixed. This is not the case with your exterior cladding, you can't just throw it away, it is protecting your family & your belongings. It is quite interesting to note that most people maintain their garden, & vehicle so they look good. Yet when it comes to cleaning the exterior windows, & walls or clearing leaves from a blocked gutter it seems to get left alone as it is perceived to be "difficult" or there are better things to do, maybe the dirt & leaves will simply disappear one day. This generally isn't the case & regular maintenance is required.

One of your major life investments is property so why not look after it? General Maintenance is a requirement of the Resene Construction Systems Performance Guarantee.

### Extent of Maintenance

The extent and nature of necessary maintenance is dependent on the

- Type of cladding or components used
- Position of cladding or components on the building
- Geographical Location of the building
- Specific site conditions.

- Areas that are considered non-maintainable
- Heavily textured areas

### **Wash Exterior Surfaces**

You will need to clean down your Resene Construction Systems Plaster Finish every 12 -18 mths. Most airborne dirt particles accumulate on exterior surfaces during the summer months. So before the winter rain washes the dirt down over the walls, give these areas a clean, this will dramatically reduce the chances of your Resene Construction Systems Plaster Finish being stained.

Washing by rain removes most atmospheric contaminants, but sheltered areas, such as walls directly below eaves, are protected from the direct effects of rain and require regular manual washing. This work should be completed using a low-pressure water blaster (300 psi or less), keep the blaster at a 45-degree angle and 300mm away from the cladding when cleaning. For best results use "Resene Roof wash and paint cleaner". Apply the diluted solution with a soft broom, & wash off with copious amounts of freshwater. Most detergents have a detrimental effect on fish life so avoid letting the washings runoff into the stormwater system. DO NOT use harsh solvent-based cleaners.

However, it is important that high-pressure water is not directed at sensitive junctions such as window surrounds and other flashings. Great care must be taken to avoid water being driven past anti-capillary gaps and flashings into the wall cavities.

### **Roof Junctions and Spouting**

When cleaning, check your spouting to make sure there are no leaves that could block drains, or overflows when it rains. Trim back branches and clear gutters at the same time. Consider fitting gutter guards (however, dirt can still get through, so you do need to check under the gutter guards from time to time). Check apron flashing diverters (kick-outs) to make sure these are diverting water away from the cladding.

### **Deck and Ground Clearances**

Exterior claddings require a minimum ground clearance to ensure no moisture gets to the timber of the wall due to capillary action. Ground clearances between the cladding and ground/deck must be maintained. For more information on required Ground Clearances refer the NZBC..

If your lawn adjoins the house, a 150-225mm wide mowing strip along the edge will stop grass and weeds growing in these difficult-to-mow areas - and keep the area drier. A mowing strip will also prevent damage to the house from hitting the cladding with the mower. You can also use concrete, bricks, pavers or treated timber for a mowing strip, laid on a concrete base or on polythene but make sure there is at least 100mm gap between the pavers and the base of the cladding.

### **Check Sealants**

Check for cracked, missing or loose sealant. You will find sealants have been used around windows, doors, electrical fittings, plumbing fittings and along the soffit line. All deteriorated sealants should be removed and resealed

### **Check hidden areas**

Check behind foliage, under decks and areas that are heavily shaded for signs of algae and mould. If possible increase the circulation of air around these points by pruning foliage. The use of mulch, bark or stones in these areas will also lower the risk of algae appearing on the surface of the coatings.

### **Damaged Areas**

Contact your Registered Plasterer they will provide the necessary expertise to remedy the damage. If you are unable to contact a registered Resene Construction Systems Plasterer call Resene Construction Systems - FreePhone 0800 50 70 40 -we will arrange for an inspection & provide an assessment for the repair the exterior cladding.

### **Non-Maintainable Areas**

Parapets are considered non-maintainable areas. They are in such a location as the degree of difficulty to maintain these areas according to the general maintenance requirements of the building code without risk to your health and safety is considered high. If you have areas that are non-maintainable we would require that these are checked every 6 months. Any non-maintainable areas will also need to be repainted/coated every 2-3 years.

### **Repainting a Dwelling**

Repainting the exterior should be undertaken by a professional painter every 7 - 10 years to ensure the integrity of the entire system is kept good. If you select a colour which has an LRV less than 25% you can expect to repaint every 7 years. It is recommended that when you repaint your dwelling that you consider the use of Resene X200 as your choice of paint.

### **Maintainable Parapet Areas utilising Liquid Membranes**

If you have areas that have maintainable liquid membrane eg.large sloping sills, balustrades, chimney breasts we would require that these are checked every 12 months. Any maintainable areas will also need to be repainted/coated every 3-5 years.

### **Important:**

*This specification must be read in conjunction with the Resene Construction Systems technical drawings.*

*No alteration to the Resene Construction Systems RenderSpec® is permitted.*

*All Technical Data Sheets are available at <https://reseneconstruction.co.nz/technical-library/technical-data-sheets/>*

*All Safety Data Sheets are available at <https://reseneconstruction.co.nz/technical-library/safety-data-sheets/>*